



CRP760

The main brush cleaning your floor.

Find matching products on the specifications tab

The roller brush is the main cleaning component of your HomeRun. When the bristles become worn out you can easily replace your brush with a new one.



Roller Brush

Specifications

Replaceable part
• Fits product type:: FC9910/01/A, FC9910/01/B

Suitable for

• HomeRun: FC9910/01/A, FC9910/01/B



Issue date 2013-03-08

Version: 2.1.1

 $\ @$ 2013 Koninklijke Philips Electronics N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com